



WLRP-001 User Manual

1. General Description & Key Features

- General Description
 - To make your presentations flow continuously, the wireless pointer integrates the slide up/down functions with a laser pointer on a remote hand help device using a wireless technology. The wireless pointers attractive and compact design enables mobility of up to 15Meters from the laptop/PC while still maintaining a full navigational control of your presentations.
 - The wireless pointer does not require any software and PC programs and take just a few seconds to install and use.
- Key Features
 - Plug and play function. No PC programming and S/W
 - Working on any computer .On any computer using a USB Prot.
 - Remote control range over 15m with a very low power .Eliminates LOS problems encountered with IR systems .
 - Transmitter identification. Use thousands of ID number to avoid multi-user interferences.

2. Terms and Explanations:

Transmitter	Receiver
 <p>The diagram shows three views of the transmitter. The front view shows three buttons labeled 'Laser Button', 'Up Button', and 'Down Button'. The side view shows a 'Lock/Unlock Switch' and a 'Battery Cover'. The back view shows a 'clip'.</p>	 <p>The diagram shows two views of the receiver. The front view shows a 'USB connector' and an 'LED Indicator'. The back view shows the reverse side of the device.</p>
<ul style="list-style-type: none"> ● Laser Button: Laser on/off control ● Up Button: Slide up control ● Down Button: Slide down control ● Lock/Unlock: To change battery 	<ul style="list-style-type: none"> LED Indicator Blinking: Connected and waiting for ID Off: ID received and waiting for command Off-On-Off: Everytime Command received

3. Installation and Usage

1. Plug the receiver into USB port. Then the LED indicator will start to blink.
2. Push either the down or up button for 1~2 seconds. The LED indicator will turn off.
3. Begin your powerpoint presentation

4. Technical Specifications

Technical Specifications	Transmitter	Receiver
Radio Frequency	315MHz(USA,Asia),4.897MHz(Europe)	
Laser Module	Wavelength:650nm(class II) Output power:<1mw	
Interface		USB HID Spec., Ver.1.1, Ver.2.0
Supported os		win98/SE/ME/2000/XP
Supported s/w		MS Office
Battery	Alkline,12V	USB Bus-powered
Operating Current	15mA	10~12mA
Dimension	115mm(L)*18mm(H)*19mm(W)	65mm(L)*7mm(H)*20mm(W)
Weight	20g	15g
Enclosure	Blue ,Silver, Black	

5. Special Notice

- Do not aim the pointer to the eye directly. It may damage the eye.
The Pointer can not be sold to Children under 19 years old.

6. Remark

In case of malfunction, Pull out and install again using a receiver or reboot a computer.

www.Pantotek.com
0086-21-58325141